



HOW TO INSTALL ARCH AND EYEBROW

1. Must decide **FIRST** which method is best to install each Arch/Eyebrow.
2. If choosing Option 1, it is best to pre-drill the hole.
3. Place Arch/Eyebrow into window opening.
4. Use level and adjust Arch/Eyebrow until it is sitting level (use bottomrail as guide).
5. Make sure the outer Trim of Arch/Eyebrow is covering the entire opening.
6. **IF INSTALLING DIRECTLY ABOVE BLIND SEE STEP 7 TO 10, OTHERWISE PLEASE SKIP TO STEP 11.**
7. Draw line on left and right side wall under Bottomrail of Arch/Eyebrow.
8. Remove Arch/Eyebrow from window.
9. Mount blind brackets using line on the wall (top of bracket should be at the line) for guidance, and install blind.
10. Place Arch/Eyebrow back in the window resting on blind brackets. (do not mount Arch/Eyebrow together with blind).
11. Secure the unit: Please refer to Option 1 or 2 below.
 - Option 1: Pre-drill hole in the crease of the outer trim located next to the bead. Then follow step 3 to 5, then use 1 1/4" Finishing nails, Tapping through pilot hole. Counter sink the nails and cover with matching color putty. Use minimum 3 nails for 48" and smaller, 5 nails for Arch/Eyebrow larger than 48".
 - Option 2: Do not Pre-drill any hole in outer trim. After completing step 3-5, rotate louvers completely open. Drill FLAT HEAD screw straight up through middle two louvers. Use minimum 3 screws for all Arch/Eyebrow. If you are able to secure through wood stud, it will make for a more secure installation.



Option 1



Option 2

**DO NOT CARRY THIS PRODUCT FROM THE TOP OF THE ARCH
THIS MAY CAUSE THE LOUVERS TO COME LOOSE.**

**CARRY PRODUCT WITH ONE HAND HOLDING BOTTOMRAIL
FOR SUPPORT.**